




Button Operation




Power On/Off




Volume Adjustment




Battery Check




Phone, Music Pairing




Music Operation




Mobile Phone Call Making and Answering



Intercom Pairing




Intercom Start/End



Radio On/Off




Radio Seek Stations




Radio Scan Up FM Band



Radio Move to Preset Station




Radio Save or Delete Preset



Setting

Configuration Menu



Using the Sena Device Manager

Connect the headset to your computer via a USB cable. Launch the Sena Device Manager and click **DEVICE SETTING** to configure the headset settings.

For details about downloading the Sena Device Manager, please refer to the leaflet included in the package.

Using the Sena Smartphone App

1. On your smartphone, download the Sena Smartphone App for Android or iPhone from Google Play or App Store. Please refer to www.sena.com for more details.
2. Pair your smartphone with the headset.
3. Run the Sena Smartphone App. Swipe the screen to the right and tap Setting to configure the headset settings.


Troubleshooting

Factory Reset

If you want to restore the 10Upad to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

Fault Reset

If the 10Upad is not working properly for any reason, reset by gently pushing the pin-hole reset button located next to the DC Power Charging & Firmware Upgrade Port.



You can download the full version of the manual and view other Sena products at the Sena website: www.sena.com.

10UPAD Quick Reference

Firmware v2.0

Type	Operation	Button Command	LED
Basic Function	Power on	Press the Center Button and the (+) Button for 1 second	Solid blue
	Power off	Tap the Center Button and the (+) Button	Solid red
	Volume adjustment	Tap the (+) Button or the (-) Button	-
Mobile Phone	Answer mobile phone call	Tap the Center Button	-
	End mobile phone call	Press the Center Button for 2 seconds	-
	Voice dial	Press the Center Button for 3 seconds	-
	Speed dial	Press the (+) Button for 3 seconds	-
	Reject incoming call	Press the Center Button for 2 seconds	-
Intercom	Intercom pairing	Press the Center Button for 5 seconds Tap the Center Button of any one of the two headsets	Red flashing
	Start/End each intercom	Tap the Center Button	-
	End all intercoms	Press the Center Button for 3 seconds	-
	Start Group Intercom	Tap the (+) Button and the (-) Button at the same time	Blue and red flashing
Music	End Group Intercom	Press the Center Button for 3 seconds	-
	Play/Pause Bluetooth music	Press the Center Button for 1 second	-
FM Radio	Track forward/back	Press the (+) Button or the (-) Button for 1 second	-
	FM radio on/off	Press the (-) Button for 1 second	-
	Select preset	Press the Center Button for 1 second	-
	Seek stations	Double tap the (+) Button or the (-) Button	-
	Scan up FM band	Press the (+) Button for 1 second	-
	Stop scanning	Press the (+) Button for 1 second	-
	Save preset while scanning	Tap the center Button	-